

## 4. Connection Illustration



1. Name and Parts



2. Package Contents



## AV Cable Button Screw Kit 9V Battery Holder

NOTE: Camera is not originally screwed with covert button head in the package. Remember to screw covert button head before use.



## 3. Application

- A. Camera connects to a portable DVR:
- 1. Install the device same as Installation 1.
- Insert AV jack into A/V IN DC 5V OUT socket of the portable DVR device. Switch to NTSC or PAL system.
- Press portable DVR POWER-ON button for 3 seconds and release the button. Note that HOLD button should switch to off position when POWER button is pressed.
- 4. A green light will turn on to show that DVR device is turn-on properly.
- 5. Press REC button to start recording.
- 6. Captured images are shown on LCD display.
- 7. Audio and video signals are collected and recorded on DVR.
- B. Camera connects to external display device:
- 1. Install the device same as Installation 2.
- Switch to NTSC or PAL system. Slide the back cover of battery holder opened. Insert the battery PP3 (9V) in proper direction. Switch to ON indication.
- The yellow and white color cable heads are to connect with the external display device (TV or LCD monitor).
- 4. Connects camera to the battery holder.
- 5. Captured images are shown on the connected external display device.
- Noted that external display device is required to connect recording device in order to record motion picture.
  (2)