


To open the device, depress the button on the top to release the latch.



The battery is secured to the base with velcro. Once the battery is removed, you may access the Micro-SD card slot.

Infra-red Remote Sensor

Auxiliary Video Output