

# About

*According to the National Association for Convenience Stores:*

*37 million Americans refuel every day.*

*Of them, 29 million pay for fuel with a credit or debit card.*

*When skimming occurs at a gas station, it usually takes place at only one pump.*

*A single compromised pump can capture data from 30 to 100 cards per day.*

**The deScammer is a device to help you avoid credit card skimming.**

---

***30% of businesses leave your credit card open to hackers***

---

## Easy to use

Use deScammer™ to protect yourself from credit card fraud. Press the button and our **portable fob device** will detect credit card skimmers at gas stations, ATMs or anywhere thieves try to steal your personal credit card info. Green means you're transaction is safe . . . **red means watch out!** A skimmer is detected. One touch detects if your credit card transaction is safe.

In the past, bad guy scammers had to return to the fuel pump or ATM to retrieve their skimmers. Today, the scammers are using Bluetooth technology to glean your credit card or debit card information. The crime is called bluesnarfing or blue skimming, and the scammers can sit 100 yards away in their vehicle while credit and debit card information is transmitted to their laptop. The deScammer Device will detect the presence of these known Bluetooth transmitters that are commonly used by the scammers.

Not ALL skimmer devices emit a transmission the deScammer only picks up transmitting devices.

It is possible to pick up other Bluetooth devices with the deScammer.

It is the users responsibility to do a physical inspection

# How it works

## Red means watch out



Red means a transmitting device has been found.

## Green means safe




Green means no transmitting device is found.

**Step 1.** Plug in USB cable and charge fully before use. A green light will appear once fully charged.

**Step 2.** When in an area of concern point the device directly at the object i.e. gas pump, the red light will begin to flash as the unit is searching for illicit signals wait for the green or red light to be solid. Unit is done detecting

**Step 3.** *Stop and Physically* look at the credit card reader. Not all skimmers, especially older ones, have a Bluetooth transmitter, so no device will help you detect them. Always take a look at the card reader to see if it looks different than the rest of the equipment in either color or age. Grasping the card reader and giving it a tug can also detect when a skimmer has been slipped over the card reader. Always use detectors and physical security.



***46% of Americans have been affected by credit card fraud***

***Disclaimer the deScammer is designed as an aid to help find credit card skimmers. It is picking up Bluetooth transmission, some credit card skimmers do not use Bluetooth. It is the user responsibility to ensure proper use and be aware of the limit of this device. KJB, deScammer and all agents are not responsible if credit card fraud occurs after use of the deScammer device.***